


Notifications

These settings are used to specify how notifications are dealt with on the phone – i.e. which apps can be activated for showing notifications, and how the notifications are displayed. The options for this are:

- **All apps.** If this is turned **On**, notifications can be received from all of the apps on the phone. If the All apps option is **Off**, notifications for individual apps can be turned **On** from the list below the All apps option.



Tap on an app to access its notification options:

- **Allow notifications.** Drag this **On** to enable notifications for a specific app.
- **Show silently.** Drag this **On** to disable any sound or vibration when a notification is received.
- **Set as priority.** Drag this **On** to enable an app's notification to override any Do Not Disturb settings.



If **All apps** is turned **On**, there could be a large number of notifications appearing on your phone, which could get rather overwhelming.



If **Show silently** is turned **On**, the **Set as priority** option is not available.